

Brilgrill — Oven & Extractor Hood Cleaner

Baked-on grease. Works cold, so no preheating trick needed.

BH0203

In short

- 750 ml, concentrated
- Removes greasy and charred cooking residue
- For ovens, extractor hoods, grills, hotplates and rotisseries
- Effective on stubborn dirt even when cold

How to use it

Oven: heat to 90 °C and switch off, spray the inside, close the door and leave for 10 minutes. Wipe with an abrasive cloth, rinse with a wet sponge, and heat the empty oven for 10 minutes before cooking in it again. Grill: spray, leave for 10 minutes, wipe with an abrasive cloth, rinse, and heat for 10 minutes before use. Deep fryer: switch off, remove the oil and food residue, spray, leave for 10 minutes, wipe, rinse and dry. For lighter dirt it can be diluted with water.

Worth knowing before you buy

- DANGER. Causes severe skin burns and eye damage.
- Wear protective gloves, eye protection and protective clothing. Do not breathe the spray or fumes.
- If it gets in the eyes: rinse cautiously with water for several minutes, remove contact lenses if easy to do, keep rinsing, and call a poison centre or doctor immediately.
- If it gets on the skin: take off contaminated clothing straight away and rinse the skin with water.
- Harmful to aquatic life with long-lasting effects — don't pour leftovers out into the environment.
-

No fragrance.

- Comes without a spray head — the trigger from an old cleaner fits.
- Contains potassium hydroxide and ethanolamine.